



7940 Memorial Drive

Plain City, OH 43064

(614) 873-4654

## **SOC Sampling Instructions – 515.3**

**(Herbicides/Chlorinated Acids)**

### **SAMPLING KIT CONTENTS**

1. 1 – 250 ml amber glass bottle with sodium thiosulfate ( $\text{Na}_2\text{S}_2\text{O}_3$ )

### **To sample:**

**DO NOT FLUSH OUT OR RINSE OUT THE SAMPLE BOTTLES**

One (1) 250ml amber glass bottle with  $\text{Na}_2\text{S}_2\text{O}_3$

1. Remove screens, filters, aerators, etc. from cold water tap.
2. Let water run for 5-10 minutes to clear any standing water.
3. Reduce water flow to a steady stream of about  $\frac{1}{4}$  inch diameter.
4. Carefully uncap the sample bottle.
5. Fill with sample water up to the neck of the bottle. When sampling from an open body of water, fill a large glass container with a representative sample and fill laboratory provided bottle(s) from the larger container.
6. Cap the bottle until it is snug.
7. Shake the bottle for ~ 15 sec.
8. Label each sample bottle.

Refrigerate the sample until you can pack it on ice for shipping.

Fill out AR Sheet / Chain of Custody to include:

- PWS ID and PWS name information
- Sample Tap, location, address, date, time and type of sample source
- Sign and date, indicate sample collection person